

## Dear customer

Thank you for purchasing this Westend Audio Systems product. You now own a versatile, excellent sounding hifi component. Before enjoying music, please read this manual carefully. After that you will know how to use your new Monaco in the optimal way.

Sincerely yours,

Stefan Trog (CEO)



## Declaration of conformity (for EC only)

We hereby confirm, that the unit to which this manual belongs fulfills the EC rules necessary to obtain the sign



the necessary measurements were taken with positive results.

Westend Audio Systems GmbH  
Siegenburgerstraße 10  
D-81373 Munich  
Germany

[www.westendaudiosystems.de](http://www.westendaudiosystems.de)  
[info@westendaudiosystems.de](mailto:info@westendaudiosystems.de)

## **Table of contents**

1	Getting started	Page 3
1.1	What's in the box	Page 3
1.2	Packaging instructions	Page 3
1.3	Control and operating elements	Page 3
1.3.1	Front panel	Page 3
1.3.2	Rear panel	Page 4
1.4	First operation	Page 4
1.4.1	Switching on for the first time	Page 4
1.4.2	Installation and cooling	Page 4
1.5	Connection to mains	Page 4
1.6	Connecting signal sources	Page 5
1.7	Connecting loudspeakers	Page 5
2	Basic operation	Page 5
2.1	Turning on and off	Page 5
2.2	Selecting the signal source	Page 6
2.3	Volume setting	Page 6
3	Remote control	Page 6
3.1	Layout	Page 6
3.2	Advanced settings	Page 8
3.2.1	Tube bias	Page 8
3.2.2	Dimming main LEDs	Page 9
3.2.3	Dimming front LEDs	Page 9
3.2.4	Setup Main Menu	Page 10
3.2.4.1	Level setup	Page 11
3.2.4.2	Fix level setting	Page 11
3.2.4.3	Shutdown/Auto-turn off	Page 13
3.2.4.4	Tube lifetime	Page 14
3.2.4.5	Leaving the setup menu	Page 15
3.2.4.6	Setup Reset / Factory default	Page 15
4	Appendix	Page 16
4.1	Cleaning	Page 16
4.2	Troubleshooting	Page 16
4.3	Conditions of warranty (EC only)	Page 16
5	Technical Data	Page 17

# 1 Getting started

## 1.1 What's in the box?

- Monaco integrated amplifier
- Power cord (in some countries)
- Remote control


## 1.2 Packaging instructions

The Monaco comes in a rugged and sturdy flight case. Please note that the flightcase is not symmetrical. If you want to put the unit into the flight case again, please ensure that it is correctly positioned.

## 1.3 Control and operating elements

The drawings below show the control elements. The operation of the unit is as follows.

### 1.3.1 Front



On the left hand side is the mode selector. It offers three operational modes – (permanently) **ON**, **OFF/IR** and **Auto**.

- By turning the selector to **Auto**, the Monaco will power on as soon as the source starts playing. After some time without signal, the Monaco powers off. In this mode one of the SOURCE-LEDs is also lit. Using the SOURCE knob you can choose the input from which the unit is triggered, when the corresponding source supplies a music signal.
- By turning the selector to **OFF/IR**, the Monaco will power on and **OFF** upon remote control command
- By turning the selector to **ON** the Monaco is permanently on and cannot be turned off with remote control (other functions of remote control will of cours work). To shut down the Monaco, the selector must be turned to **OFF/IR**. Then the MONACO will switch to standby within 2 seconds.

**REMARK:** While powered on the Monaco can be controlled completely by remote control, only the power on and power off functions are affected by the mode chosen.


In the middle of the front panel is the volume control knob – it shows the volume chosen by

LED the actual volume setting is indicated by the LED ring around the volume knob. When the volume knob is turned slowly the Monaco changes the volume in 0,5dB steps and the LED switches to the next one after seven clicks on the remote control seven times. When the knob is turned faster, volume will change more coarse.

If you press Mute on the remote control, the most left LED of the LED ring is lit red. Pressing MUTE again or changing volume by remote control or volume knob will unmute the MONACO

The knob on the right side selects the input. The corresponding LED is ON.

### **1.3.2 Rear panel**



The elements on of the rear panel are from left to right:

- Right channel loudspeaker output
- Pre-out XLR/balanced
- Fix-out RCA/Cinch for e.g. Headphone amplifiers
- Inputs 4-5 RCA/Cinch
- Inputs 1-3 XLR/balanced
- Left channel loudspeaker output
- Connector for SW updates, phase-control\* LED, connector for external IR receiver
- AC power connector

\* Correct mains phase means the LED is dark. So if the phase indicator is lit, unplug the powercord from walls outlet and reinsert it turned by 180°.

## **1.4 First operation**

### **1.4.1 Switching on for the first time**

**IMPORTANT NOTE:** Before the Monaco is operated for the first time, it is mandatory to start the auto bias! See chapter 3.2.1 of this manual

### **1.4.2 Installation and cooling**

**CAUTION:** *The tubes will become very hot and should never be touched while the Monaco is turned on!*

**Also - under no circumstances – never try to unplug the anode connecors (caps) of the EL130 tubes !**

- Position the unit such that unhindered air flow to the bottom plate is guaranteed.
- Do NOT put the unit on a carpet. This might prevent the air flow into the air vents in bottom plate and thus overheat the unit.
- Direct exposure to sunlight is not recommended – this may affect the surface.

### **1.5 Connection to mains**

Set the switch on rear panel to OFF. Then connect the unit to the mains outlet by using the power cord which is (in some countries) supplied together with the unit or another suitable power cord. Make sure that mains voltage is according to the specification printed on the rear panel of the amp (near mains connector).

**CAUTION:** Keep the unit switched off until all audio connections are made.

### **1.6 Connecting signal sources**

You can connect up to five analog line sources to your Monaco. Connect the outputs of your signal sources to the inputs of the Monaco on the rear side of the unit. The upper row of the RCA/Cinch or XLR connectors is for left channels (white), the lower row is for right channels (red).

### **1.7 Connecting loudspeakers**

The Monaco has one speaker outlet per channel. Use only good speaker cables with sufficient diameter. Make sure that the red terminals are connected to the red or "+" terminals of the speakers and the black terminals to the black or "-" terminals of the speakers.

## **2 Basic operation**

### **2.1 Turning on and off**

When the Monaco powers on, it starts by heating up the tubes gradually.

This power up procedure takes about 40 seconds and is indicated by the LED ring around the volume control and the input LEDs. With each cycle all volume LEDs are gradually lit and the input LEDs are lit one by one.

If the unit is set to standby all LEDs except the corresponding MODE LED (and in case of AUTO-mode additionally one of the SOURCE-LEDs) are off.

**CAUTION:** *Even while switched to stand-by the unit is still connected to the mains. In case of a thunderstorm or if you leave the house for longer time we recommend that you switch the amplifier off by using the mains switch on rear panel or pull the mains plug.*

## **2.2 Selecting the signal source**

Use the input selector to select a signal source. The selected source is indicated by LED.

## **2.3 Volume setting**

Use the volume knob to set the desired volume. The volume increases / decreases in 0.5 dB steps while knob is turned slowly and more coarse while knob is turned faster.

The same principle is valid for remote control: Short presses onto the volume keys will change volume by 0.5 dB steps, If you press for a longer time, volume will change faster.

## **3 Remote control**



### **3.1 Layout**

The remote control has ten buttons in total – the assignment is as follows:

Top row:

Left: Off/Standby/Tube adjust



Right: On/Operation



Second row:

Left: Setup Menu



Right: Mute



Third row:

Left: Balance left



Right: Balance right



Fourth row:

Left: source down



Right: source up



Bottom row:

Left: Volume down

Right: Volume up




## **3.2 Advanced settings**

### **3.2.1 Tube bias**

**NOTE:** We recommend to perform the automatic bias every 1-2 months.

This is how to proceed: First set mode selector to OFF/IR. To start the auto bias press and hold the buttons **Setup** and **X** (Off/Tube adjust) simultaneously for five seconds until the four LEDs around the input selector start flashing.



Now the amplifier sets the tube bias automatically. This procedure will last about 15 minutes. – if one of the tubes fails, the LED indicating the position of the tube is the only LED not lit!


The order of the LED/tubes are from left to right:

Input 1: Tube on the far left

Input 2: Tube second from left

Input 3: Tube second from right

Input 4: Tube on the far right



**Do not turn off the device during the bias progress and wait until the amplifier switches into standby!**




**NOTE:** If mains voltage fails or you switch the MONACO off by mistake during the auto bias procedure, it will for safety reasons continue after mains is switched on again until the procedure is fully completed. During this time, you the amp cannot be operated.

When the bias setting is completed you may turn on the amplifier and listen to music.


### **3.2.2 Main illumination brightness (upper LEDs)**

Press and hold the button **Setup** and press either **DIM Main** (left) or **DIM Main** (right) to increase or decrease the upper main lighting

Button combination for decreasing main LED lighting:




Button combination for increasing main LED lighting:




### **3.2.3 Dimming front LEDs**

Press and hold the button **Setup** and press either **DIM Front** (left) or **DIM Front** (right) to increase or decrease the LED brightness on the front panel

Button combination for decreasing front LED:




Button combination for increasing front LED:



### **3.2.4 Setup Menu**


The MONACO offers several settings for configuring it to your own requirements. These (not often used) settings can be accessed by the MENU

To enter the setup menu the unit must be in ON state. **Press and hold** the **Setup** button until the **lower two** LEDs on the operation selector are lit. This indicates that you have entered the MENU.






### **3.2.4.1 Level setup: (lower two LEDs lit/default Setup main menu)**

Now you are in the setup menu „level setting“ (refer to the backside of the remote control for pictograms and explanations)



*While in this menu, the level of the actual selected station may be adjusted to personal preferences with the volume buttons of the remote control or the volume knob. While doing that you may select the sources using the SOURCE knob and this way equalize the levels of the different sources.*




### **3.2.4.2 Fix level setting (the upper two LEDs are lit)**

In a surround system the channel balance, tone setting and bass management are done by the decoder. This setting must not be altered by another component because the channel balance then would be incorrect. For this application the MONACO offers the fixed gain function.


Set the input where the main channels of the surround system are connected to fixed gain.

When this input is selected, balance is set to neutral position and the gain is on a fixed level independently of the volume setting on the other inputs.

To enter the fixlevel menu, **press** the **Setup** button again so that the **upper two** LEDs on the operation selector are lit.





*Now you can activate or deactivate the fix level function for the desired input (input can be chosen using the SOURCE selector on front panel or by remote control). The actual setting is signalized by LED combinations around the volume knob. See drawings below.*



*This LED combination shows the variable status of input 1*


*Press the volume down button, station 1 changes to fixed status.*





*This LED combination shows the fixed status of input 1*


*Press the volume up button, input changes to variable status again*




*This setting is recommended if the Monaco should be integrated into a home cinema system or to use it as power amplifier.*



### **3.2.4.3 Shutdown/Auto-turn off setting (upper and lower LED lit)**

To adjust the automatic shutdown time, **press Setup** again so that the upper and lower LEDs of the operation selector are lit.







*While in this menu, the shutdown time of the amplifier can be adjusted with the volume buttons of the remote control. Per LED lit the time is 10 minutes. Factory setting is 10 minutes (one LED lit)*



#### **3.2.4.4 Tube lifetime (all three LEDs are lit)**

To see the tube lifetime, please press Setup again so that all three LEDs of the operation selector are lit.






*This menu point is of informative character only, there is no possibility of any adjustment here.*

### **3.2.4.5 Leaving the setup menu**


To leave the setup menu, please press Setup once again!



After leaving the setup menu, **only one LED** of the MODE selector will be lit!

### **3.2.4.6 Setup Reset / Factory default**

To reset the Monaco to factory default settings, please push and hold the buttons **Setup** and **On** simultaneously for about five seconds while unit is ON.



## **4 Appendix**

### **4.1 Cleaning**

Use a soft cloth and normal glass cleansing fluid.

**CAUTION:** *Make sure that no fluid comes into the unit. Do not use scouring cleaners. They may damage the surface.*

### **4.2 Troubleshooting**

Some putative defects are often caused by small mistakes in operation. Sometimes, other units connected to the amplifier may cause problems, too. We therefore kindly ask you to read the following tips first, before consulting your dealer or us.

#### 1. No playback

Mute function is active, press button MUTE on your remote control or increase the volume using the volume knob or the volume keys on remote control.

#### 2. Inadvertent switching to stand by.

Turn the operation selector to On. If the LED indicator does not light up, a fuse might be blown due to overvoltage (e.g. in case of a thunderstorm etc.). Please contact your dealer.

### **4.3 Conditions of warranty (EC only)**

If despite expectations a defect occurs that cannot be repaired by yourself or your dealer, we undertake the repair of your unit free of charge for up to two years from date of purchase, six months for the tubes.

Provisions for this warranty are:

- The unit must have been purchased from an authorized dealer. Equipment from other sources will not be repaired, not even at charge.
- The defect must not have been caused by improper handling or misuse.
- Return the unit to us only in its original packing. If this is not possible we are entitled to refuse acceptance. We will not assume responsibility for transport damage under any circumstances.
- A short description of the defect is to be included with the returned unit.
- We also reserve the right to levy a handling charge for items returned without good or valid reason, or if the unit proves to be not defective.



## **5 Technical Data**

Output power	2 x 100W (4 $\Omega$ )
Tube equipment	4x E130L, 4x ECC82
Inputs RCA	2x stereo
Inputs XLR	3x stereo
Pre-out XLR	1x stereo
Fix-out RCA	1x stereo
Loudspeaker outputs	1 pair
Dimensions (W x H x D)	47 x 23 x 38 cm
Weight	46,0 Kg

**Issued 1<sup>st</sup> June 2018, changes reserved without notice.**